

Windows PC Technical Support – Frequently Asked Questions & Troubleshooting Guide

1. PC is Running Very Slow

Problem

My Windows PC has become very slow during startup and while opening applications.

Troubleshooting Steps

1. Restart the computer.
 2. Disable unnecessary startup programs:
 - Press Ctrl + Shift + Esc
 - Open the **Startup** tab
 - Disable unwanted applications
 3. Free disk space:
 - Open **Settings → System → Storage**
 - Remove temporary files
 4. Run Disk Cleanup:
 - Search for **Disk Cleanup**
 5. Scan for malware using Windows Security.
 6. Update Windows and device drivers.
 7. Upgrade RAM or switch to SSD if performance is still poor.
-

2. Wi-Fi Not Connecting

Problem

The laptop cannot connect to Wi-Fi or shows “No Internet”.

Troubleshooting Steps

1. Restart the router and PC.
2. Turn Wi-Fi off and on.
3. Forget and reconnect to the network:

- Settings → Network & Internet → Wi-Fi
4. Run Windows Network Troubleshooter.
 5. Update Wi-Fi drivers:
 - Device Manager → Network Adapters
 6. Run these commands in Command Prompt as Administrator:

`ipconfig /flushdns`

`ipconfig /release`

`ipconfig /renew`

`netsh winsock reset`

7. Check if airplane mode is enabled.
-

3. Blue Screen Error (BSOD)

Problem

The system suddenly crashes with a blue screen.

Troubleshooting Steps

1. Note the error code displayed.
2. Restart the computer.
3. Boot into Safe Mode.
4. Update drivers and Windows.
5. Check RAM using Windows Memory Diagnostic.
6. Run system file checker:

`sfc /scannow`

7. Check disk health:

`chkdsk /f /r`

8. Uninstall recently installed software or drivers.
-

4. Printer Not Working

Problem

The printer is connected but does not print.

Troubleshooting Steps

1. Ensure printer is powered on.
 2. Check USB or Wi-Fi connection.
 3. Set printer as default:
 - Settings → Bluetooth & Devices → Printers & Scanners
 4. Clear stuck print queue.
 5. Restart Print Spooler service.
 6. Reinstall or update printer drivers.
 7. Print a test page.
-

5. Windows Update Failed

Problem

Windows updates are failing or stuck.

Troubleshooting Steps

1. Restart the PC.
2. Run Windows Update Troubleshooter.
3. Ensure sufficient disk space.
4. Restart Windows Update service.
5. Clear SoftwareDistribution folder.
6. Run:

`DISM /Online /Cleanup-Image /RestoreHealth`

`sfc /scannow`

7. Retry Windows Update.
-

6. Laptop Overheating

Problem

The laptop becomes very hot and shuts down unexpectedly.

Troubleshooting Steps

1. Clean air vents and cooling fans.
 2. Use the laptop on a hard surface.
 3. Close high CPU-consuming applications.
 4. Check Task Manager for abnormal processes.
 5. Update BIOS and drivers.
 6. Replace thermal paste if necessary.
 7. Use a cooling pad.
-

7. No Sound from Speakers

Problem

The system has no audio output.

Troubleshooting Steps

1. Check speaker/headphone connections.
 2. Increase system volume.
 3. Ensure correct playback device is selected.
 4. Restart Windows Audio service.
 5. Update audio drivers.
 6. Run Audio Troubleshooter.
 7. Reinstall sound drivers if needed.
-

8. USB Device Not Recognized

Problem

A USB device is not detected by Windows.

Troubleshooting Steps

1. Reconnect the USB device.
 2. Try another USB port.
 3. Restart the computer.
 4. Update USB drivers.
 5. Disable USB power saving.
 6. Test the device on another PC.
 7. Check Device Manager for errors.
-

9. Unable to Login to Windows

Problem

User cannot log in to Windows account.

Troubleshooting Steps

1. Verify keyboard layout and Caps Lock.
 2. Restart the computer.
 3. Use password reset options.
 4. Boot into Safe Mode.
 5. Use another administrator account.
 6. Run Startup Repair.
 7. Restore system using System Restore.
-

10. Applications Crashing Frequently

Problem

Applications close unexpectedly or freeze.

Troubleshooting Steps

1. Restart the application.
2. Update the application.
3. Reinstall the application.
4. Check system compatibility.

5. Update graphics drivers.
6. Scan for malware.
7. Check Event Viewer for logs.

Additional Best Practices

- Keep Windows updated.
- Install antivirus software.
- Regularly back up important files.
- Avoid installing unknown software.
- Create restore points periodically.
- Monitor disk health and system temperature.